


Soil and asphalt compaction. Trenches and pipeline projects, backfill, foundations, patching and asphalt repair.







Applications: Soil and asphalt compaction, Interlocking blocks, repair and maintenance, patching, sports fields and landscaping.

BP 10/35

BP 12/40

BP 20/50

BP 20/50 D

BP 25/50

BP 25/50 D

BVP 10/30

BP 12/50 A\*








Honda

Honda

Honda

Туре
BPR 2 BPR 2 BPR 2 BPR 3 BPR 3 BPR 3 BPR 4 BPR 4 BPR 5 BPR 5 BPR 6 BPR 6



Operating Weight (CECE) kg

72

109

108

Working

500

500

500

500

500

300

Width



Soil and asphalt compaction, paving. Highway and footpath construction and maintenance, backfill, trenches and pipelines, sportsgrounds and landscaping, interlocking blocks and groundworks.



ype	Operating Weight (CECE) kg	Working Width mm	Engine
PR 25/40 PR 25/40 D PR 25/50 PR 25/50 D PR 35/42 D PR 35/42 D PR 35/60 D PR 45/60 D PR 45/45 PR 45/55 D PR 50/55 D PR 50/65 D PR 60/65 PR 70/70 D PR 100/80 D PH 80/65 S*	135 150 140 155 190 210 205 225 260 340 400 405 455 420 460 580 700 750	400 400 500 500 420 420 600 600 450 550 650 650 650 650 800 800	Honda Hatz Honda Hatz Honda Hatz Honda Hatz Honda Hatz Honda Kohler Hatz Kohler Honda Hatz Kohler Hatz Kohler Hatz Honda Hatz Honda Hatz Hatz Hatz Hatz



Working

630

630

680

680

Width

Concrete blocks, natural stones (cut: diamond cut), non-bevelled stones, large formats, sensitive surfaces and stone formats, large surfaces, and sensitive surrounding objects.

Weight (CECE) kg

228

248

435

447

BPR 25/50 D

BPR 35/60

BPR 35/60 D

BPR 50/55 [

BPR 55/65 D



Engine	
Hatz Honda Hatz Hatz Kohler Honda	
Hatz	



Applications: Soil and asphalt compaction. Construction and maintenance of pavements, shoulders, walking and cycle tracks, access and parking areas, sports and playgrounds, forestry and estate roads.

Туре	Operating Weight (CECE) kg	Working Width mm	Engine
BW 55 E	150	560	Honda
BW 71 E-2	488	710	Hatz
BW 65	720	650	Honda
BW 65 D	740	650	Kohler
BW 75 H	1040	750	Yanmar



Applications: Soil compaction. Trenches and pipelines, backfill and foundations – wherever high mobility, manoeuvrability and simple handling are required on difficult soils.



Туре	Operating Weight (CECE) kg	Working Width mm	Engine
BMP 8500*	1595	610/850	Kubota/Kohler

Standard with combination remote control cable/radio

# The company:

BOMAG is the global leader in the field of compaction technology. The company, which has its HQ in Boppard and has belonged to the FAYAT group since 2005, produces machines for soil, asphalt and refuse compaction as well as stabilizers / recyclers, milling machines and pavers.

The company has six branches in Germany and 12 independent subsidiaries. Over 400 dealers in more than 150 countries guarantee the global distribution of BOMAG machines and their maintenance.

### www.bomag.com

- Head Office/Hauptsitz:
  BOMAG. Hellerwald. 56154 Boppard. GERMANY. Tel.: +49 6742 100-0. e-mail: info@bomag.com, www.bomag.com
- BOMAG Maschinenhandelsgesellschaft m.b.H., Klausenweg 654, 2534 Alland, AUSTRIA, Tel.: +43 2258 20202, e-mail: austria@bomag.com
- BOMAG MARINI EQUIPAMENTOS LTDA., Avenida Clemente Cifali, 530,
- Distrito Industrial Ritter, Cachoeirinha RS, BRAZIL, ZIP code 94935-225 Tel.: +55 51 2125-6642, e-mail: brasil@bomag.com
- BOMAG (CANADA), INC., 2233 Argentia Road, East Tower, Suites 302, L5N 2X7,
- Mississauga, ON, CANADA, Tel.: +1 800 782 6624, e-mail: canada@bomag.com BOMAG (CHANGZHOU) Construction Machinery Co. Ltd., No. 66 Bopa Road,
- Xuejia Town, Xinbei District, Changzhou 213125, CHINA, Tel.: +86 21 33655566, e-mail: china@bomag.com BOMAG India Pvt Ltd, Unit No 614, B Wing, 6th Floor, Kanakia Wall Street,
- Chakala Andheri Kurla Road Andheri East, Mumbai 400 093 Maharashtra, INDIA, Tel.: +91 8657492418, e-mail: india@bomag.com
- BOMAG FRANCE S.A.S., 2, Avenue du Général de Gaulle, 91170 Viry-Châtillon, FRANCE,
- Tel.: +33 1 69578600, e-mail: france@bomag.com
- BOMAG (GREAT BRITAIN), LTD., Sheldon Way, Larkfield, Aylesford, Kent ME20 6SE, GREAT BRITAIN, Tel.: +44 1622 716611, e-mail: gb@bomag.com
- BOMAG Italia, Via Roma 50, 48011 Alfonsine, ITALY,
- Tel.: +39 0544 864235, e-mail: italv@bomag.com
- FAYAT BOMAG Polska Sp. z o.o., Ul. Szyszkowa 52, 02-285 Warszawa, POLAND, Tel.: +48 22 482 04 00, e-mail: poland@bomag.com
- FAYAT BOMAG RUS 000, 141400, RF, Moscow region, Khimki, Klayazma block, h. 1-g, RUSSIA, Tel: +7 (495) 287 92 90, e-mail: russia@bomag.com
- BOMAG GmbH, 300 Beach Road, The Concourse, #18-06, Singapore 199555, SINGAPORE, Tel.: +65 294 1277, e-mail: singapore@bomag.com
- BOMAG Americas, Inc., 125 Blue Granite Parkway, Ridgeway SC 29130, U.S.A., Tel.: +1 803 3370700, e-mail: usa@bomag.com

\* Remote control, hydraulic drive

Machines may be shown with options.

# **Tampers**

### Different tamper foot widths

Suitable working widths for flexible applications ranging from small trenches to areas with high surface coverage. Optional side protection plates as an additional

wear protection for the tamper foot. 160\*, 200\*, 230, 240\*, 280, 290\* and 330\* mm

\* incl. side protection



### Tamper foot extensions

Flexible operation when working in narrow, deep trenches (e.g. mini-trenching). Operator does not need to stand in the trench.

150 x 120 mm (b x h)

100 x 370 mm (b x h) 150 x 370 mm (b x h)



Facilitate the manual transport of a tamper even on rough ground. Puncture-proof tyres. Mechanism suitable for all models.



### Rechargeable batteries and chargers

to power the BT 60 e unit. Vibration-resistant design, tool-free installation and full compaction power at the touch of a button.

Battery variants: eP 20 (20Ah) eP 28 (28Ah)

Standard charger (recharging time <4h) Quick charger (recharging time <2h)



### Water spraying system for asphalt work

The water spraying system distributes the water evenly across the whole working width and prevents asphalt from sticking to the base plate For BPR 25/40, BPR 25/40 D, BPR 25/50, BPR 25/50 D and all single direction vibratory plates except BVP 10/30.



# The middle position is an alternative to the

standard position of the guide handle and increases the machine's manoeuvrability which allows to work easily along walls corners and

BP 12/50 A, BP 20/50, BP 25/50.

### Comfort handle

The HAV values of the machine are below

Regulation-compliant and fatigue-free working. Simplification of the risk assessment.

For all BPs and BVPs except for BVP 12/50 A.



### Vulkolan mat for paving work

Easy to install.

To effectively use the vibratory plate during

Protects the paving stones, prevents marks and reduces the risk of breakage.

Not for BPH 80/65 S, BPR 100/80 D, BP 12/50 A



For all single direction and reversible vibratory

Facilitate the manual transport of a vibratory plate even on rough and loose ground Puncture-proof tyres. For all vibratory plates < 350 kg (not for

BVP 10/30 and BVP 12/50 A).



# **Hand-guided Vibratory Rollers**

### Cleaning rod

A rod and a holding fixture used for fast and easy cleaning of scrapers and spray tubes. For BW 65 and BW 65 D.



### Warning light

Increased safety through visual warning with flashing LED. For BW 65 and BW 65 D.



**Multi-purpose compactor** 

Sturdy and comfortable remote control.

Standard on BMP 8500, BPH 80/65 S.

Electric starter with warning buzzer o start the machine comfortably. Available for the reversible vibratory plates:

BPR 35/42 D, BPR 35/60 D, BPR 40/60 D.

Electric starter as BPR series > 350 kg.

replaceable extension plates Flexible working widths thanks to replaceable extension plates.

Flexible working widths thanks to

Suitable working widths for every application ranging from small trenches to areas with high surface coverage.

For reversible vibratory plates > 350 kg. Not for BPH 80/65 S.



Steering with both hands possible at any time. Full control over the machine thanks to direction change using only one thumb and a safety



To clean the gaps on the whole width of the

Standard on BMP 8500.

# **Light Equipment**

Contain all necessary parts which are required for servicing and maintaining the machines. Simple and safe ordering of all the needed parts.

Special paintwork

Painting the machine with an own design.



## **Extended warranty.**

Options: Extended warranties for new machines.



**WARRANTY OPTIONS:** 

Available for the complete Light Equipment range.

**EXTENDED** 

You can find additional information in your price list as well as in your service documents.



# 3-2-1 warranty as a standard

If you offer high quality, you can also give extensive warranty cover



pe	3 years	2 years	1 year
nper	Spring and guide unit	Combustion engine Electric motor / Batteries	Standard warranty
<b>BVP</b> gle Direction atory Plates	Exciter gears	Combustion engine	Standard warranty
R ersible Vibratory des	Exciter gears + Hydraulic travel lever control	Combustion engine	Standard warranty
<b>f</b> ersible Hydraulic tes	Exciter gears + Vibration motor / -pump	Combustion engine	Standard warranty
ndguided Vibratory ers	Exciter unit + Clutch + Vibration drive	Combustion engine	Standard warranty
<b>P</b> tipurpose npactor	Exciter gears + Vibration motor / -pump + Drum	Combustion engine	Standard warranty





PRODUCT GUIDE

LIGHT EQUIPMENT.



The BOMAG warranty conditions apply.

**BOMAG**FAYAT GROUP

With integrated city mode. BPR 70/70 D, BPR 100/80 D. and BVP 12/50 A.

Adjustable scrapers

Width adjustable for operation without drum

### Displays degree of compaction in real time. This

saves time and costs by avoiding unnecessary passes and always achieving the optimum leve of compaction. Warns against overcompaction and grain breakage and identifies weak spots in the ground. BPR > 350 kg, BMP 8500.

**ECONOMIZER**